

NVT(300K)->NVT(100K)

```

variable a loop 5
variable t index 55555 66666 77777 88888 99999
label loop
clear
# Lennard-Jones Melt
#-----Prepare Geometry-----
-----
units                lj
atom_style            atomic
read_data             LJ_256.in.data
#read_restart         ljNVE.restart.1000000
#-----Initialize Structure-----
-----
mass                 1 1.0
group                Ar type = 1
#-----LJ Potentials-----
-----
pair_style            lj/cut 2.5
pair_coeff             * * 1.0 1.0
pair_modify           shift yes
#pair_modify          tail no
#-----Variables-----
-----
#LJ Parameters
variable             kB                equal 1.3806504e-23 # [J/K] Boltzmann
variable             sigma_Ar          equal 3.4e-10      # m
variable             eps_Ar            equal 1.67e-21     # J
variable             mass_Ar           equal 6.63e-26     # kg
variable             tau_Ar            equal 2.1423e-12    # s

variable             T_melt            equal 300*({kB}/{eps_Ar})
variable             T_0K              equal 0.001
variable             T_run             equal 100*({kB}/{eps_Ar})
#variable             V                equal vol
variable             dt equal 0.002
#variable             p equal 200 # correlation length
#variable             s equal 10 # sample interval
#variable             d equal $p*$s # dump interval

log log$a.lammps

#----- NVT RUN -----
-----
velocity             all create ${T_melt} $t dist gaussian mom yes
fix                  1 all nvt temp ${T_melt} ${T_melt} 10.0
thermo_style          custom step temp press etotal pe ke vol xlo xhi ylo yhi zlo
zhi
thermo                500
timestep              ${dt}
run                   100000
#                      run             2500
unfix 1
#----- NVT RUN -----
-----
fix                  1 all nvt temp ${T_melt} ${T_run} 10.0
run                   250000
#                      run             2500
unfix 1
#----- NPT RUN -----
-----
reset_timestep        0

```

```

fix          1 all npt temp ${T_run} ${T_run} 10.0 iso 0.0 0.0 10.0
compute      myDis Ar msd
dump         xyz all xyz 100000 npt_reheat_dump.$a
thermo_style custom step temp press etotal pe ke vol xlo xhi ylo yhi zlo
zhi c_myDis[4]
thermo       500
run          250000
#           run          2500
undump       xyz
unfix        1
uncompute    myDis
#----- NPT RUN -----
-----
reset_timestep 0
fix          1 all npt temp ${T_run} ${T_run} 10.0 iso 0.0 0.0 10.0
compute      myDis Ar msd
dump         xyz all xyz 100000 npt_${T_run}_dump.$a
#-----Calculate Avg Cell Size-----
-----
variable     myLx equal xhi-xlo
fix          myLx all ave/time 100 10 1000 v_myLx file Lx.profile$a
variable     myLx2 equal f_myLx
thermo_style custom step temp press etotal pe ke vol xlo xhi ylo yhi zlo
zhi c_myDis[4]
thermo       500
run          500000
#           run          10000
undump       xyz
unfix        1
fix          deform all deform 1 x final 0.0 ${myLx2} y final 0.0
${myLx2} z final 0.0 ${myLx2} units box
run          10000
unfix        deform
unfix        myLx
uncompute    myDis
#----- NVT RUN -----
-----
reset_timestep 0
fix          1 all nvt temp ${T_run} ${T_run} 10.0
compute      myDis Ar msd
thermo_style custom step temp press etotal pe ke vol xlo xhi ylo yhi zlo
zhi c_myDis[4]
thermo       500
run          100000
uncompute    myDis
unfix        1
#----- kappa -----
-----
reset_timestep 0
fix          1 all nve
timestep     ${dt}
compute      myDis Ar msd
thermo_style custom step temp press etotal pe ke vol xlo xhi ylo yhi zlo
zhi c_myDis[4]
thermo       500
run          250000
#           run          2500
unfix        1
uncompute    myDis

log          log_kappa$a.lammps
fix          1 all nve
reset_timestep 0


```

```


compute          myKE all ke/atom
compute          myPE all pe/atom
compute          myStress all stress/atom virial
compute          flux all heat/flux myKE myPE myStress
variable         Jx equal c_flux[1]/vol
variable         Jy equal c_flux[2]/vol
variable         Jz equal c_flux[3]/vol
compute          myDis Ar msd
thermo_style      custom step temp press etotal pe ke vol c_myDis[4] v_Jx
v_Jy v_Jz
thermo           5
dump             xyz all xyz 500000 nve_kappa_dump.$a
timestep         ${dt}
run              2000000
#               run              2500
unfix            1
uncompute        myKE
uncompute        myPE
uncompute        myStress
uncompute        flux

next t
next a
jump in.LJAr.melt loop


```



NPT to measure average cell size



NVE



MSD

